



## **NOTE:**

The maximum decoration area is a guide only and is grealty dependant on the logo shape.







## **NOTE:**

The maximum decoration area is a guide only and is grealty dependant on the logo shape.

SUPACOLOUR / SCREENPRINT

## EX3359 FABRIC SWATCH

**BLACK** BLACK

Pantone colours are provided as a reference only and are based on closest match. Actual product colour may differ. If a precise colour match is required we recommend ordering a sample.